



**NOTES:**

1. IF CLEAN-OUT IS INSTALLED IN DRIVEWAY, USE CHRISTY G5 TRAFFIC VALVE BOX WITH "SEWER" CAST IN LID (OR APPROVED EQUAL). BOX SHALL HAVE A CONCRETE COLLAR. (SEE DETAIL SS-5 FOR DETAILS OF CONCRETE COLLAR)
2. WHEN PROPERTY LINE IS AT BACK OF WALK, INSTALL CLEAN-OUT BEHIND BACK OF WALK.
3. PROVIDE STOPPER WHEN THERE IS NO ON-SITE LATERAL CONNECTION.
4. MATERIAL FOR THE CLEANOUT PIPE SHALL MATCH THE MATERIAL FOR THE LATERAL. SEE CITY'S SPECIFICATIONS FOR MATERIALS.



DRAWN BY: M. LEE  
 CHECKED BY: S. THACH  
 APPROVED BY: T. SUPAN  
 DATE: AUGUST 2006

**SANITARY SEWER CLEAN-OUT**

CITY OF SANTA CLARA

**SS-1**

PAGE: 28